



Optima

PRODUCT MANUAL

10 massage modes

Snail clit attachment

Waterproof IPX7

**Made from silicone
and ABS plastic**



Charging

- For maximum pleasure, charge before every use.
- Connect the included USB cable and insert the USB end into the wall adaptor or computer USB port (Computer must be turned on).
- The slow, intermittent glow indicates charging in progress.
- A full charge takes up to 150 minutes for 70 minutes of play.
- Do not use the device while charging.



Magnetic USB
charging port

How To Use

- Hold the  button to turn on/off.
- Press the  button quickly to cycle through 10 massage modes.

Travel mode

- Hold both buttons at the same time for 3 seconds. The light will flash twice, and after that, the toy will enter travel mode.
- Pressing any button, including turning the toy on while the mode is activated, is impossible.
- To exit travel mode, put the toy on charge or press the power button three times consecutively.



Cleaning and Care

- Use a toy cleaner/mild soap with water to clean the product before and after each use.
- Pat with a towel and allow it to air-dry completely.
- Use with water-based lube only, no silicone lubricants.
- Please avoid contact with silicone or silicone-containing materials as it may damage the product.



Warning

- Do not use on inflamed and/or injured areas.
- Discontinue use if feeling pain or discomfort.
- Adult novelty only. Use for medical purposes and/or use that has an adverse effect on any function of the body is prohibited.

edenfantasy
THE NEW INTIMACY

www.edenfantasy.com

Customer Service
10 AM - 7 PM EST
Phone: +1 (770) 604 - 1352