ed@nfantasys



Pleasure ridges for extra stimulation


Removable vibrating bullet

Waterproof

Made from silicone and ABS plastic

Power

- The item is powered by 3 LR41 batteries (included).
- Remove the protective film from the battery compartment before use.



Oral sex vibro enhancer

PRODUCT MANUAL

How To Use

 Hold the button to turn the vibration on/off.





Cleaning and Care

- Use a toy cleaner/mild soap with water to clean the product before and after each use.
- Pat with a towel and allow it to air-dry completely.
- Use with the water-based lube only, no silicone lubricants.



Warning

- Do not use on inflamed and injured areas.
- Discontinue use if feeling pain or discomfort.
- Adult novelty only. Use for medical purposes or for a use that has an adverse effect on any function of the body is prohibited.

edenfantasys

www.edenfantasys.com

Customer Service 24/7 Phone: +1 (770) 604 - 1352