ed@nfantasys



2 powerful motors

30 massage modes

Rabbit clitoral attachment

Realistic design

Made from skin-like TPR material and ABS plastic

Power

- The item is powered by 2 AAA batteries.
- Unscrew the base to insert the batteries.
- Follow the polarity instructions inside the battery case.
- When storing for an extended period, please remove batteries from the toy.



Perky Vibe

PRODUCT MANUAL

How To Use

- Press the **b** button to turn the toy on/off.
- Press the W button quickly to cycle through 30 massage modes.



Cleaning and Care

- Use a toy cleaner/mild soap with water to clean the product before and after each use.
- Pat with a towel and allow it to air-dry completely.
- Store away from other toys to avoid chemical reactions and damage to either toy.
- Dust lightly with talc or cornstarch for better use.
- Store away from heat and sunlight.
- Use with water-based lube only, no silicone lubricants.

Warning

- Do not use on inflamed and injured areas.
- Discontinue use if feeling pain or discomfort.
- Adult novelty only. Use for medical purposes or for a use that has an adverse effect on any function of the body is prohibited.

edenfantasys

www.edenfantasys.com

Customer Service 10 AM - 7 PM EST Phone: +1 (770) 604 - 1352