



Pink dream

PRODUCT MANUAL

**Soft pleasure ticklers
and ridges**

Removable bullet

**Made from soft TPR
and ABS plastic**

Power

- The item is powered by 3 LR44 batteries (included).
- Unscrew the base of the bullet to open the battery compartment.



3 LR44
batteries

How To Use

- Rotate the dial base to turn vibration on/off.
- Wear on any finger to power up your touch.



Cleaning and Care

- Remove the bullet for thorough cleaning.
- Use a toy cleaner/mild soap with water to clean the product before and after each use.
- Pat with a towel and allow it to air-dry completely.
- Do not get water inside the bullet as it is not waterproof.
- Use with the water-based lube only, no silicone lubricants.



Warning

- Do not use on inflamed and injured areas.
- Discontinue use if feeling pain or discomfort.
- Adult novelty only. Use for medical purposes or for a use that has an adverse effect on any function of the body is prohibited.

edenfantasys
THE NEW INTIMACY

www.edenfantasys.com

Customer Service 24/7
Phone: +1 (770) 604 - 1352