edénfantasys





Pleasure rocket

10 stroking modes 10 massage modes Texturized tunnel LCD display Turbo mode Made from skin-like TPE and ABS plastic

PRODUCT MANUAL

Charging

- For maximum pleasure charge before every use.
- Connect the included USB cable and insert the USB end into the wall adaptor or computer USB port (Computer must be turned on).
- The slow intermittent glow indicates charging in progress.
- A full charge takes up to 2 hours for 1 hour of play.
- Do not use the device while charging.



How To Use

- Remove the cap to start your play.
- Hold the 🖒 button to turn on/off.
- Press the **N** button quickly to cycle through 10 stroking modes.
- Hold it to turn the stroking mode off.
- Press the **I** button quickly to cycle through 10 massage modes.
- Hold it to turn the massage mode off.
- Press the button to turn turbo mode on/off.
- Press the 🍟 button to cycle through 6 light modes.



Cleaning and Care

- Remove the donut and take the sleeve out of the plastic case for thorough cleaning.
- Carefully remove the corded bullet from the sleeve.



- Use a toy cleaner/mild soap with water to clean the sleeve before and after each use.
- Pat with a towel and allow it to air-dry completely.



- Dust lightly with talc or cornstarch for better use. Store away from heat and sunlight.
- Do not get water inside the case as it is not waterproof. Wipe it down with the wet cloth/tissue and dry it out completely before inserting the sleeve.
- Insert the bullet into the hole inside the sleeve.

- Insert the sleeve into the plastic case.
- Insert and rotate the donut clockwise matching the grooves to finish the assembly.



- Store away from other toys to avoid chemical reactions and damage to either toy.
- Use with the water-based lube only, no silicone lubricants.

edénfantasys

www.edenfantasys.com

Warning

- Do not use on inflamed and/or injured areas.
- Discontinue use if feeling pain or discomfort.
- Adult novelty only. Use for medical purposes and/or use that has an adverse effect on any function of the body is prohibited.

Customer Service 10 AM - 7 PM EST Phone: +1 (770) 604 - 1352