



Pocket massager kit

PRODUCT MANUAL

3 fun attachments

Powerful vibration

Waterproof

Made from ABS plastic

Power

- The item is powered by 1 AA battery.
- Unscrew the base of the item to insert the battery.



1 AA battery

How To Use

- Rotate the dial control to turn on/off.
- Adjust the dial control to increase/reduce vibration intensity.



— Dial base

Cleaning and Care

- Use a toy cleaner/mild soap with water to clean the product before and after each use.
- Pat with a towel and allow it to air dry completely.
- Use with water, silicone or oil-based lubricant.



Warning

- Do not use on inflamed and injured areas.
- Discontinue use if feeling pain or discomfort.
- Adult novelty only. Use for medical purposes or for a use that has an adverse effect on any function of the body is prohibited.

edenfantasy
THE NEW INTIMACY

www.edenfantasy.com

Customer Service 24/7
Phone: +1 (770) 604 - 1352