



Realistic multispeed vibrator

PRODUCT MANUAL

Multi-speed vibrations

Realistic design

Made from skin-like
TPR material and ABS
plastic

Power

- The item is powered by 2 AA batteries.
- Unscrew the base of the item to insert the batteries.
- Follow the polarity instructions inside the battery case.



2 AA
batteries

How To Use

- Rotate the dial base to turn vibration on/off.
- Adjust the dial base to increase/reduce the vibration intensity.



Dial
control

Cleaning and Care

- Use a toy cleaner/mild soap with water to clean the product before and after each use.
- Pat with a towel and allow it to air-dry completely.
- Dust lightly with the corn starch for better use.
- Store away from heat and sunlight.

Use with the water-based lube only, no silicone lubricants.



Warning

- Do not use on inflamed and injured areas.
- Discontinue use if feeling pain or discomfort.
- Adult novelty only. Use for medical purposes or for a use that has an adverse effect on any function of the body is prohibited.

edenfantasy
THE NEW INTIMACY

www.edenfantasy.com

Customer Service 24/7
Phone: +1 (770) 604 - 1352