edenfantasys



Realistic pussy and ass with vibrating bullets

PRODUCT MANUAL

Realistic design

Two textured pleasure tunnels

Two removable vibrating bullets

Features seductive moans

Made from skin-like TPR material and ABS plastic

Power

- The item is powered by 3 AAA batteries.
- Open the compartment to insert the batteries.
- Follow the polarity instructions inside the battery case.



3 AAA batteries

How To Use

- Insert the bullets in the openings at the back of the masturbator.
- Press the left button to turn the vibration on/off.
- Press the right button to turn the seductive moans on/off.

Vibration



Cleaning and Care

- Remove the bullets for thorough cleaning.
- Use a toy cleaner/mild soap with water to clean the product before and after each use.
- Pat with a towel and allow it to air-dry completely.
- Do not get water inside the bullets and control pack as they are not waterproof.
- Use with the water-based lube only, no silicone lubricants.



Warning

- Do not use on inflamed and injured areas.
- Discontinue use if feeling pain or discomfort.
- Adult novelty only. Use for medical purposes or for a use that has an adverse effect on any function of the body is prohibited.

edenfantasys

www.edenfantasys.com

Customer Service 24/7 Phone: +1 (770) 604 - 1352