edenfantasys



Realistic Thrusting Bunny

PRODUCT MANUAL

9 thrusting and rotation modes

9 massage modes

Heats up to 104° F

Remote control

Waterproof

Strong suction cup

Made from silicone and ABS plastic

Charging

- For maximum pleasure charge before every use.
- Connect the included USB cable and insert the USB end into the wall adaptor, power bank or computer USB port (Computer must be turned on).
- The slow intermittent glow indicates charging in progress.
- A full charge takes up to 1.5 hours for 1 hour of play.
- Do not use the device while charging.



Magnetic USB charging port

How To Use

Without remote control

- Hold the **b** button on the toy's base to turn on/off.
- Press it quickly to cycle through 9 thrusting and massage modes.



With remote control

- Hold the **b** button on the toy's base for standby mode.
- Press the button on the remote quickly to cycle through 9 thrusting and rotating modes.
- Press the w button on the remote quickly to cycle through 9 massage modes.
- Hold the **b** button on the remote to turn the toy off.



Heating

- Press the button to turn the heating mode on.
- Allow up to 5 minutes for the toy to warm up.

Cleaning and Care

- Use a toy cleaner/mild soap with water to clean the product before and after each use.
- Pat with a towel and allow it to air-dry completely.
- Use with the water-based lube only, no silicone lubricants.
- Please avoid contact with silicone or silicone-containing materials as it may damage the product.

Warning

- Do not use on inflamed and injured areas.
- Discontinue use if feeling pain or discomfort.
- Adult novelty only. Use for medical purposes or for a use that has an adverse effect on any function of the body is prohibited.

edenfantasys

www.edenfantasys.com

Customer Service 10 AM - 7 PM EST Phone: +1 (770) 604 - 1352