



Rechargeable thrusting butterfly

PRODUCT MANUAL

**3 rows of pleasure
beads**

**4 thrusting & rotation
speeds**

**12 vibration modes for
clit stimulator**

**Butterfly-shaped
clitoral stimulator**

**Made from soft TPR
material and ABS
plastic**

Waterproof










Charging

- For maximum pleasure charge before every use.
- Unscrew the base of the item to insert the USB cable.
- Connect the included USB cable and insert the USB end into the wall adaptor or computer USB port (Computer must be turned on).
- The slow intermittent glow indicates charging in progress.
- A full charge takes up to 3 hours for 1 hour of play.



USB
charging port

How To Use

- Hold the  button to turn on/off.
- Press the  button to turn on the vibration.
- Press the  or  buttons to cycle through 12 vibration modes.
- Press the  button to turn off the vibration.
- Press the  button to turn on thrusting and beads rotation.
- Press the  or  buttons to cycle through 4 thrusting & rotation speeds.
- Press the  button to turn off thrusting and beads rotation.



Cleaning and Care

- Use a toy cleaner/mild soap with water to clean the product before and after each use.
- Pat with a towel and allow it to air-dry completely.
- Dust lightly with the corn starch for better use.
- Store away from heat and sunlight.
- Use with the water-based lube only, no silicone lubricants.



Warning

- Do not use on inflamed and injured areas.
- Discontinue use if feeling pain or discomfort.
- Adult novelty only. Use for medical purposes or for a use that has an adverse effect on any function of the body is prohibited.

edenfantasy
THE NEW INTIMACY

www.edenfantasy.com

Customer Service 24/7
Phone: +1 (770) 604 - 1352