edénfantasys



Remote control pleasure egg

PRODUCT MANUAL

10 vibration modes

Travel-friendly design

Made from velvet-coated plastic

Waterproof

Power

- The item is powered by 2 AAA batteries (included).
- Unscrew the base to insert the batteries.
- Follow the polarity instructions inside the battery case.



How To Use

With the remote control

- The remote is powered by a button cell battery (included, not replaceable).
- Hold the 😃 button to turn on/off.
- Press the △ or ▽ button to cycle through 10 powerful modes.



Cleaning and Care

- Use a toy cleaner/mild soap with water to clean the product before and after each use.
- Pat with a towel and allow it to air-dry completely.
- Use with water, silicone or oil-based lubricant.



Warning

- Do not use on inflamed and injured areas.
- Discontinue use if feeling pain or discomfort.
- Adult novelty only. Use for medical purposes or for a use that has an adverse effect on any function of the body is prohibited.

edénfantasys

www.edenfantasys.com

Customer Service 24/7 Phone: +1 (770) 604 - 1352