edenfantasys



Rose tongue pump

PRODUCT MANUAL

Sucking mode

7 licking modes

2 removable suction cups

2 independent motors

Made from silicone and ABS plastic

Charging

- For maximum pleasure charge before every use.
- Connect the toy to the included magnetic charging base and insert the USB end into the wall adaptor or computer USB port (Computer must be turned on).
- The slow intermittent glow indicates charging in progress.
- A full charge takes up to 120 minutes for 80 minutes of play.
- Do not use the device while charging.



Magnetic charging base

How To Use

Suction Mode

- Put the cup attachment over the tongue.
- Press the toy to your labia or nipple so the sucking cup surrounds the desired area.
- Hold the button to activate the suction mode - a gentle tugging sensation should appear.
- When you feel the suction intensity is enough, release the suction button. The product will keep sucking steadily.
- Double press the button to activate the suck-and-release mode.
- Double press again to turn the suck-and-release mode off.
- Hold the button to increase suction intensity.

Licking Mode

- Double press the putton to turn the licking mode on/off.
- Press it quickly to cycle through 7 licking modes.
- If the tongue is not in the middle

vertical position, shortly press the licking button within 3 minutes after turning the toy off to return the tongue to the middle vertical position.



Cleaning and Care

- Use a toy cleaner/mild soap with water to clean the product before and after each use.
- Pat with a towel and allow it to air-dry completely.
- Use with water-based lube only, no silicone lubricants.
- Please avoid contact with silicone or silicone-containing materials as it may damage the product.

Warning

IF PAIN OR DISCOMFORT OCCURS, IMMEDIATELY RELEASE THE SUCTION BUTTON AND DISCONTINUE USE.

- Do not use on inflamed and/or injured areas.
- Discontinue use if feeling pain or discomfort.
- Adult novelty only. Use for medical purposes and/or use that has an adverse effect on any function of the body is prohibited.



www.edenfantasys.com

Customer Service 10 AM - 7 PM EST Phone: +1 (770) 604 - 1352