edénfantasys



Rowdy vibrating realistic dildo

PRODUCT MANUAL

10 massage modes

Realistic design

Strong suction cup

Made from phthalate-free PVC and ABS plastic

Power

- Insert 2 AAA batteries to power the control pack.
- Unscrew the of the control pack and insert the batteries into the battery compartment.
- Follow the polarity instructions inside the battery case.



How To Use

- Hold the button to turn on/off.
- Press it quickly to cycle through 10 massage modes.



Cleaning and Care

- Use a toy cleaner/mild soap with water to clean the product before and after each use.
- Pat with a towel and allow it to air dry completely.
- Use with the water-based or silicone-based lubricant.



Warning

- Do not use on inflamed and injured areas.
- Discontinue use if feeling pain or discomfort.
- Adult novelty only. Use for medical purposes or for a use that has an adverse effect on any function of the body is prohibited.

edénfantasys

www.edenfantasys.com

Customer Service 10 AM - 7 PM EST Phone: +1 (770) 604 - 1352