# ed@nfantasys



**Secret pleaser** 

PRODUCT MANUAL

# 2 powerful motors

10 air pulse and licking modes

10 massage modes

Wearable design

Remote controlled

Waterproof

Made from silicone and ABS plastic

# Charging

- For maximum pleasure charge before every use.
- Connect the included USB cable and insert the USB end into the wall adaptor or computer USB port (Computer must be turned on).
- The glow indicates charging in progress.
- A full charge takes up to 55 minutes for 55 minutes of play.
- Do not use the device while charging.



Magnetic USB charging port

## **How To Use**

#### Without remote control

- Hold the **U** button to turn the toy on/off. The LED light will flash.
- Press it quickly to cycle through 10 massage, air pulse and licking modes.

#### With the remote control

- Hold the **t** button on the toy to enter the standby mode. The LED light will flash.
- Press the W button on the remote to cycle through 10 massage modes.
- Hold it to turn the massage mode off.
- Press the \$\begin{align\*}{l}\$ button on the remote to cycle through 10 air pulse and licking modes.
- Hold it to turn the air pulse and licking modes off.



### **Cleaning and Care**

- Use a toy cleaner/mild soap with water to clean the product before and after each use.
- Pat with a towel and allow it to air-dry completely.
- Use with the water-based lube only, no silicone lubricants.



# Warning

- Do not use on inflamed and injured areas.
- Discontinue use if feeling pain or discomfort.
- Adult novelty only. Use for medical purposes or for a use that has an adverse effect on any function of the body is prohibited.



www.edenfantasys.com

Customer Service 10 AM - 7 PM EST Phone: +1 (770) 604 - 1352