



Sensualist

PRODUCT MANUAL

**10 rotation and
massage modes**

2 independent motors

Turbo mode

Realistic design

Strong suction cup

Made from silicone



Charging

- For maximum pleasure, charge before every use.
- Connect the included USB charging cable and insert the USB end into the wall adaptor or computer USB port (Computer must be turned on) or power bank.
- The slow, intermittent glow indicates charging in progress.
- A full charge takes up to 90 minutes for 100 minutes of play.
- Do not use the device while charging.



USB charging port

How To Use

- Hold the  button to turn on/off. The LED light will flash.
- Press it quickly to cycle through 10 massage and rotation modes.
- Press the  button for an intensity burst (fades after 20 secs).



Cleaning and Care

- Use a toy cleaner/mild soap with water to clean the product before and after each use.
- Pat with a towel and allow it to air-dry completely.
- Use with water-based lube only, no silicone lubricants.
- Please avoid contact with silicone or silicone-containing materials as it may damage the product.



Warning

- Do not use on inflamed and injured areas.
- Discontinue use if feeling pain or discomfort.
- Adult novelty only. Use for medical purposes or for a use that has an adverse effect on any function of the body is prohibited.

www.edenfantasy.com

Customer Service
10 AM - 7 PM EST
Phone: +1 (770) 604 - 1352