ed@nfantasys



Sex engine

12 vibration modes

Memory function

Realistic opening

Made from skin-like TPR material

Multi-angle suction cup

Power

- The item is powered by 2 AAA batteries.
- Unscrew the base of the item to insert the batteries
- Follow the polarity instructions inside the battery case.



Before Use

- Take the cap off to begin play.
- Pull the latch down to secure the suction cup.
- Adjust for a comfortable angle.

How To Use

- Hold the 🖒 button to turn on/off.
- Press the W button quickly to cycle through 12 vibration modes.



Cleaning and Care

- Take the sleeve out of the plastic case for thorough cleaning.
- Use a toy cleaner/mild soap with water to clean the product before and after each use.
- Pat with a towel and allow it to air-dry completely.
- Use with the water-based lube only, no silicone lubricants.



Warning

- Do not use on inflamed and injured areas.
- Discontinue use if feeling pain or discomfort.
- Adult novelty only. Use for medical purposes or for a use that has an adverse effect on any function of the body is prohibited.



www.edenfantasys.com

Customer Service 24/7 Phone: +1 (770) 604 - 1352