



Simple Pleasures Multispeed Vibrating Egg

PRODUCT MANUAL

Multiple massage intensities

Powerful motor

Discreet size

Made from ABS plastic


Power

- The item is powered by 2 AAA batteries (not included).
- Open the control pack lid to insert the batteries.
- Follow the polarity instructions inside the battery case.



How To Use

- Attach the egg to the control pack.
- Rotate the dial control to turn on/off.
- Adjust the dial control to increase/reduce massage intensity.



Cleaning and Care

- Use a toy cleaner/mild soap with water to clean the product before and after each use.
- Pat with a towel and allow it to air-dry completely.
- Use with water-based, silicone, or oil-based lubricants.



Warning

- Do not use on inflamed and injured areas.
- Discontinue use if feeling pain or discomfort.
- Adult novelty only. Use for medical purposes or for a use that has an adverse effect on any function of the body is prohibited.

Customer Service from 10 AM to 7 PM EST. Phone: +1 (770) 604 - 1352

edénfantasys

www.edenfantasys.com