



Smooch

3 Sucking modes

7 licking modes

7 massage modes

**2 removable
suction cups**

**Made from silicone
and ABS plastic**

Charging

- For maximum pleasure charge before every use.
- Connect the included USB cable and insert the USB end into the wall adaptor or computer USB port (Computer must be turned on).
- The slow intermittent glow indicates charging in progress.
- A full charge takes up to 2 hours for 45 minutes of play.
- Do not use the device while charging.



USB charging port

How To Use

Suction Mode

- Put the cup attachment over the tongue.
- Press the toy to your labia or nipple so the sucking cup surrounds the desired area.
- Hold the  button to turn the toy on/off.
- Press the it quickly to cycle through the 3 suction modes - a gentle tugging sensation should appear.



Power
Button

Licking Mode

- Press the  button quickly to cycle through the 7 licking and massage modes.

Cleaning and Care

- Use a toy cleaner/mild soap with water to clean the product before and after each use.
- Pat with a towel and allow it to air-dry completely.
- Use with the water-based lube only, no silicone lubricants.
- Please avoid contact with silicone or silicone-containing materials as it may damage the product.

Warning

IF PAIN OR DISCOMFORT OCCURS,
IMMEDIATELY TURN THE TOY OFF AND
DISCONTINUE USE

- Do not use on inflamed and/or injured areas.
- Discontinue use if feeling pain or discomfort.
- Adult novelty only. Use for medical purposes and/or use that has an adverse effect on any function of the body is prohibited.

edenfantasy
THE NEW INTIMACY

www.edenfantasy.com

Customer Service
10 AM - 7 PM EST
Phone: +1 (770) 604 - 1352