



## Soft kisser

PRODUCT MANUAL

---

**Rotating tongue**

---

**3 licking speeds**

---

**5 licking modes**

---

**3 sucking modes**

---

**Waterproof IPX6**

---

**Made from TPE and  
ABS plastic**

## Charging

---

- For maximum pleasure charge before every use.
- Connect the included USB cable and insert the USB end into the wall adaptor or computer USB port (Computer must be turned on).
- The glow indicates charging in progress.
- A full charge takes up to 90 minutes for 60 minutes of play.
- Do not use the device while charging.




Magnetic USB  
charging port

## How To Use

---

- Hold the  button to turn the toy on/off.
- Press it quickly to cycle through 3 speeds and 5 modes of licking.
- The 3 sucking modes work in a cycle, changing as you change the licking modes.



## Cleaning and Care

---

- Use a toy cleaner/mild soap with water to clean the product before and after each use.
- Pat with a towel and allow it to air-dry completely.
- Dust lightly with talc or cornstarch for better use.
- Store away from heat and sunlight.
- Use with the water-based lube only, no silicone lubricants.
- Store away from other toys to avoid chemical reactions and damage to either toy.

## Warning

---

- Do not use on inflamed and injured areas.
- Discontinue use if feeling pain or discomfort.
- Adult novelty only. Use for medical purposes or for a use that has an adverse effect on any function of the body is prohibited.

**edenfantasy**  
THE NEW INTIMACY

[www.edenfantasy.com](http://www.edenfantasy.com)

Customer Service  
10 AM - 7 PM EST  
Phone: +1 (770) 604 - 1352