

## **PRODUCT SPECIFICATIONS**

Materials: Silicone, ABS
7 Thrusting Speeds
7 Vibrations Patterns
Heats up to 100 F

Includes: Power unit, Silicone Dildo, Suction Cup Stand,

Remote Control, Manual

# **MAINTENANCE**

- For better experience always apply a water-based lubricant.
- For cleaning, disassemble the dildo from the power unit. Wash the dildo with warm water and cleaner and allow it to dry completely before using it.
- The power unit shouldn't be submerged into the water.
   To clean, wipe it down with the disinfecting solution.
- Keep away from the direct sunlight.





Designed in USA

Made in China

www.EdenFantasys.com

## 1) Charge before first use



- Flashing light indicates charging and low charge.
- Steady light indicates full charge.

#### (2) Attaching the dildo



- Open the cup.
- Insert the attachment matching the grooves.
- Rotate the attachment counterclockwise until you hear the click.
- To dismantle the machine rotate the dildo clockwise and pull it out.

### (3) The stand instructions



- Screw the unit on top of the stand.
- Adjust the angle.
- Tighten the knob to hold the position.
- Loosen the knob to change the angle.

#### Suction cup

- Position the cup on the smooth surface.
- Use the toggle to close the cup or open it.

#### (4) Built-in Control



 $\bigcirc$ 

 $\bigcirc$ 

 $\alpha$ 

 $\circ$ 

 Thrusting control: Quick press to start or change speed. Hold to turn

- Vibration control: Quick press to start or change patterns. Hold to turn it off.
- Heat control: Hold to turn it on/off. The temperature reaches 100 F.

#### (5) Remote Control



 Thrusting control: Quick press to start or change speed. Hold to turn it off.

 Vibration control: Quick press to start or change patterns. Hold to turn it off.