edénfantasys



Splendor

PRODUCT MANUAL

2 powerful motors

7 vibration modes

Memory function

Perfect gift

Waterproof

Made from silicone and zinc alloy

Charging

- For maximum pleasure, charge before every use.
- Connect the included USB cable and insert the USB end into the wall adaptor or computer USB port (Computer must be turned on).
- The slow intermittent glow indicates charging in progress.
- A full charge takes up to 2 hours for 50 minutes of play.



USB charging port

How To Use

- Hold the top *NV* button to turn the main shaft on/off.
- Press it quickly to cycle through 7 vibration modes.
- Hold the bottom *NV* button to turn the clitoral attachment on/off.
- Press it quickly to cycle through 7 vibration modes.



Cleaning and Care

- Use a toy cleaner/mild soap with water to clean the product before and after each use.
- Pat with a towel and allow it to air-dry completely.
- Use with the water-based lube only, no silicone lubricants.



Warning

- Do not use on inflamed and injured areas.
- Discontinue use if feeling pain or discomfort.
- Adult novelty only. Use for medical purposes or for a use that has an adverse effect on any function of the body is prohibited.

edénfantasys

www.edenfantasys.com

Customer Service 24/7 Phone: +1 (770) 604 - 1352