



Sweet pie

PRODUCT MANUAL

Realistic design

Multi-speed vibration

**Removable
vibrating bullet**

**Made from
skin-like TPR material
and ABS plastic**

Power

- The item is powered by 2 AA batteries.
- Open the compartment to insert the batteries.
- Follow the polarity instructions inside the batteries' case.



2 AA
batteries

How To Use

- Insert the bullet in the opening at the back of the masturbator.
- Rotate the dial control to turn on/off.
- Adjust the dial control to increase/reduce the vibration intensity.



Cleaning and Care

- Use a toy cleaner/mild soap with water to clean the product before and after each use.
- Pat with a towel and allow it to air dry completely.
- Use with the water-based lube only, no silicone lubricants.



Warning

- Do not use on inflamed and injured areas.
- Discontinue use if feeling pain or discomfort.
- Adult novelty only. Use for medical purposes or for a use that has an adverse effect on any function of the body is prohibited.

edenfantasy
THE NEW INTIMACY

www.edenfantasy.com

Customer Service 24/7
Phone: +1 (770) 604 - 1352