



Swell cock

PRODUCT MANUAL

Multispeed vibrations

Inflatable shaft

Made from skin-like
TPR material

Suction cup

Power

- Insert 2 AA batteries to power the control pack.
- Open the lid to insert the batteries.
- Follow the polarity instructions inside the battery case.



2 AA
batteries

How To Use

- Apply water-based lubricant on yourself and the toy before starting the play.
- Insert the toy and begin pumping slowly - you should feel a gentle stretching sensation.
- Press Quick Release Valve before removing the toy.

With control pack

- Rotate the dial control to turn on/off.
- Adjust the dial control to increase/reduce vibration intensity.



Cleaning and Care

- Use a toy cleaner/mild soap with water to clean the product before and after each use.
- Pat with a towel and allow it to air-dry completely.
- Dust lightly with the corn starch for better use.
- Store away from heat and sunlight.
- Use with the water-based lube only, no silicone lubricants.



Warning

IF PAIN OR DISCOMFORT OCCURS, IMMEDIATELY RELEASE PRESSURE USING QUICK RELEASE VALVE AND DISCONTINUE USE.

- Do not use on inflamed and injured areas.
- Adult novelty only. Use for medical purposes or for a use that has an adverse effect on any function of the body is prohibited.

edenfantasy
THE NEW INTIMACY

www.edenfantasy.com

Customer Service 24/7
Phone: +1 (770) 604 - 1352