edénfantasys



Thrusting mini bunny

PRODUCT MANUAL

Thrusting motion

3 vibration speeds

3 beads rotation speeds

Two-way rotation

Made from soft TPR material and ABS plastic

Splashproof

Power

- The item is powered by 3 AAA batteries.
- Unscrew the base to insert the batteries.
- Follow the polarity instructions inside the battery case.



3 AAA batteries

How To Use

- Press the + button to turn on the vibration.
- Press the + or buttons to adjust vibration intensity.
- Press the button to turn off the vibration.
- Press the + button to turn on thrusting and beads rotation.
- Press the + or buttons to adjust thrusting and beads rotation intensity.
- Press the button to turn off thrusting and beads rotation.
- Press the button to change the direction of beads rotation.



Cleaning and Care

- Use a toy cleaner/mild soap with water to clean the product before and after each use.
- Pat with a towel and allow it to air-dry completely.
- Dust lightly with the corn starch for better use.
- Store away from heat and sunlight.
- Use with the water-based lube only, no silicone lubricants.



Warning

- Do not use on inflamed and injured areas.
- Discontinue use if feeling pain or discomfort.
- Adult novelty only. Use for medical purposes or for a use that has an adverse effect on any function of the body is prohibited.

edénfantasys

www.edenfantasys.com

Customer Service 24/7 Phone: +1 (770) 604 - 1352