# ed@nfantasys



**Triple O Butterfly** 

PRODUCT MANUAL

# 2 powerful motors

7 massage modes

**Pulsating membrane** 

Perineum stimulation

**Butterfly attachment** 

Remote control

Waterproof

Made from silicone and ABS plastic

## **Charging (USB charging port)**

- For maximum pleasure charge before every use.
- Connect the included USB cable and insert the USB end into the wall adaptor or computer USB port (Computer must be turned on).
- The glow indicates charging in progress.
- A full charge takes up to 3 hours for 1 hour of play. Do not use the device while charging.
- The remote control is powered by 1 CR2032 battery (included).



### **How To Use**

#### Without remote control

- Hold the button to turn the toy on/off. The LED light will flash.
- Press the W button to cycle through 7 massage and pulsation modes.

#### With remote control

- Hold the button on the toy to enter the standby mode. The LED light will flash.
- Press the button on the remote to cycle through 7 massage and pulsation modes.
- Hold it to pause the toy.



Power Button

## **Cleaning and Care**

- Use a toy cleaner/mild soap with water to clean the product before and after each use.
- Pat with a towel and allow it to air-dry completely.
- Use with water-based lube only, no silicone lubricants.



## Warning

- Do not use on inflamed and injured areas.
- Discontinue use if feeling pain or discomfort.
- Adult novelty only. Use for medical purposes or for a use that has an adverse effect on any function of the body is prohibited.



www.edenfantasys.com

Customer Service 10 AM - 7 PM EST Phone: +1 (770) 604 - 1352