edénfantasys



Vibrating hollow strap-on

PRODUCT MANUAL

7 vibration modes

Realistic design

Adjustable straps

Made from silicone

Power

- The control pack is powered by 2 AAA batteries.
- Open the compartment to insert the batteries.
- Follow the polarity instructions inside the batteries' case.



Before Use

- Apply lubricant on yourself and inside the toy before use.
- Slide your legs into the straps and adjust the fit.

How To Use

- Hold the 😃 button to turn on/off.
- Press the *W* button quickly to cycle through 7 vibration modes.



Cleaning and Care

- Use a toy cleaner/mild soap with water to clean the product before and after each use.
- Pat with a towel and allow it to air dry completely.
- Use with the water-based lube only, no silicone lubricants.



Warning

- Do not use on inflamed and injured areas.
- Discontinue use if feeling pain or discomfort.
- Adult novelty only. Use for medical purposes or for a use that has an adverse effect on any function of the body is prohibited.



www.edenfantasys.com

Customer Service 24/7 Phone: +1 (770) 604 - 1352