



Vibrating prostate massager

PRODUCT MANUAL

C-shape design

**Nubbed base for
perineum stimulation**

Waterproof

**Made from TPR and
ABS plastic**

Power

- The item is powered by 4 LR44 batteries (included).
- Unscrew the base of the bullet to insert the batteries.
- Remove the protective film from the battery compartment before use.



4 LR44
batteries

How To Use

- Press the button to turn on/off.



Cleaning and Care

- Use a toy cleaner/mild soap with water to clean the product before and after each use.
- Pat with a towel and allow it to air-dry completely.
- Dust lightly with the corn starch for better use.
- Use with the water-based only, no silicone lubricants.



Warning

- Do not use on inflamed and/or injured areas.
- Discontinue use if feeling pain or discomfort.
- Adult novelty only. Use for medical purposes and/or use that has an adverse effect on any function of the body is prohibited.

edenfantasy
THE NEW INTIMACY

www.edenfantasy.com

Customer Service 24/7
Phone: +1 (770) 604 - 1352