



# Vibro blow

PRODUCT MANUAL

---

**5 suction modes**

---

**10 massage modes**

---

**Texturized tunnel**

---

**Made from skin-like  
TPE, silicone and ABS  
plastic**

## Charging

---







- For maximum pleasure, charge before every use.
- Connect the included USB cable and insert the USB end into the wall adaptor or computer USB port (Computer must be turned on).
- The slow intermittent glow indicates charging in progress.
- A full charge takes up to 180 minutes for 80 minutes of play.
- Do not use the device while charging.



**Magnetic  
charging port**

## How To Use

---

- Hold the  button to turn on/off.
- Press the  quickly to cycle through 5 suction modes.
- Press the  button to turn suction mode off.
- Press the  button quickly to cycle through 10 massage modes.
- Hold the  button to turn vibration off.
- Hold the  button to activate uninterrupted suction mode. Once you release the button, the suction stops.



Power  
button

## Cleaning and Care

---

- Use a toy cleaner/mild soap with water to clean the sleeve before and after each use.
- Pat the sleeve with a towel and allow it to air-dry completely.
- Dust lightly with talc or cornstarch for better use. Store away from heat and sunlight.
- Do not get water inside the case as it is not waterproof. Wipe it down with the wet cloth/tissue and dry it out completely before use.
- Use with the water-based lube only, no silicone lubricants.
- Store away from other toys to avoid chemical reactions and damage to either toy.



## Warning

---

- Do not use on inflamed and injured areas.
- Discontinue use if feeling pain or discomfort.
- Adult novelty only. Use for medical purposes or for a use that has an adverse effect on any function of the body is prohibited.

**edenfantasys**  
THE NEW INTIMACY

[www.edenfantasys.com](http://www.edenfantasys.com)

Customer Service  
10 AM - 7 PM EST  
Phone: 1 (770) 604 - 1352