



Vibro Squeeze

PRODUCT MANUAL


10 vibrating modes

Waterproof IPX6

**Made from ABS
plastic and silicone**


Charging

- For maximum pleasure charge before every use.
- Connect the included USB cable and insert the USB end into the wall adaptor or computer USB port (Computer must be turned on).
- The slow intermittent glow indicates charging in progress.
- A full charge takes up to 3 hours for 1 hour of play.
- Do not use the device while charging.



USB charging port

How To Use

- Hold the  button to turn on/off.
- Press it quickly to cycle through 9 vibration modes.

LIMIT THE USE OF THE NIPPLE CLAMPS TO NO LONGER THAN 15 MINUTES PER USE.



Cleaning and Care

- Use a toy cleaner/mild soap with water to clean the product before and after each use.
- Pat with a towel and allow it to air-dry completely.
- Use with water, silicone or oil-based lubricant.



Warning

- Do not use on inflamed and injured areas.
- Discontinue use if feeling pain or discomfort.
- Limit the use of the nipple clamps to no longer than 15 minutes per use.
- Allow at least 60 mins between uses as more frequent use may increase the risk of injury to the nipples.
- Do not fall asleep while wearing the nipple clamps since prolonged use may cause injury to the nipples.

- Do not use the nipple clamps under the influence of alcohol or drugs, since it may impair the user's judgment and increase the risk of injuring the nipples.
- Misuse of nipple clamps may cause bruising, painful injury, or permanent damage to the nipples.
- Adult novelty only. Use for medical purposes or for a use that has an adverse effect on any function of the body is prohibited.

edenfantasys
THE NEW INTIMACY

www.edenfantasys.com

Customer Service
10 AM - 7 PM EST
Phone: 1 (770) 604 - 1352