edénfantasys



Viking realistic vibrator

PRODUCT MANUAL

Power

- The item is powered by 2 AAA batteries.
- Unscrew the base to insert the batteries.
- Follow the polarity instructions inside the battery case.



Multi-speed vibration

Made from soft TPR material

Waterproof



How To Use

- Rotate the dial control to turn on/off.
- Adjust the dial control to increase/ reduce the vibration intensity.



Cleaning and Care

- Use a toy cleaner/mild soap with water to clean the product.
- Pat with a towel and allow it to air dry completely.
- Use with the water-based lube only, no silicone lubricants.
- The item can be sterilized with a 5% bleach solution or alcohol.



Warning

- Do not use on inflamed and injured areas.
- Discontinue use if feeling pain or discomfort.
- Adult novelty only. Use for medical purposes or for a use that has an adverse effect on any function of the body is prohibited.

Customer Service 24/7 Phone: +1 (770) 604 - 1352

edénfantasys

www.edenfantasys.com