

10 vibration modes

Oversized tongue-shaped clit attachment

LED lights

Made from silicone

Waterproof

Zeal

PRODUCT MANUAL

Charging

- For maximum pleasure charge before every use.
- Connect the included USB cable and insert the USB end into the wall adaptor or computer USB port (Computer must be turned
- on).
 The slow intermittent glow
- indicates charging in progress.
 A full charge takes up to 3 hours for 1 hour of play.

USB charging port

Cleaning and Care

- Wash with warm water and soap before and after each use.
- Use a toy cleaner/mild soap with water to clean the product.
- Pat with a towel and allow it to air-dry completely.
- Use with the water-based lube only, no silicone lubricants.
- The item can be sterilized with a 5% bleach solution or alcohol.

How To Use

- Apply water-based lubricant on your shaft.
- Wear around the penis or penis and testicles.
- Hold the button to turn on/off.
- Press it quickly to cycle through 10 vibration modes.
- If pain or discomfort occurs, immediately remove the constriction ring.

LIMIT THE USE OF THE CONSTRICTION RING TO NO LONGER THAN 30 MINUTES PER USE

With the remote control

- Insert 1 CR2032 battery to power the remote.
- Hold the button on the remote to turn on/off.
- Press the w button quickly to cycle through 10 vibration modes.

Warning

- Stop using the constriction ring if pain occurs.
- Do not fall asleep while wearing the constriction ring, since prolonged use may cause permanent injury to the penis.

- Allow at least 60 mins between uses, as more frequent use may increase the risk of injury to the penis.
- Do not use the constriction ring under the influence of alcohol or drugs, since it may impair the user's judgment and increase the risk of injury to the penis.
- Misuse of a constriction ring may cause bruising, painful injury, or permanent damage to the penis.
- Constriction rings do not prevent pregnancy.



Precautions

• Use of a constriction ring may aggravate already existing conditions, such as Peyronie's disease (the formation of hardened tissue in the penis that causes pain, curvature, and distortion, usually during erection); priapism (persistent, usually painful erection of the penis as a consequence of disease and not related to sexual arousal); and urethral strictures (urethral stricture is an area of hardened tissue, which narrows the urethra, sometimes making it difficult to urinate).

- Prolonged use of the constriction ring (i.e., without removal) may cause permanent injury to the penis.
- Incorrect use of this device may bruise or hurt the blood vessels within the penis or scrotum, resulting in petechiae (a small purplish spot on a body surface, such as skin or a mucous membrane, caused by a minute hemorrhage), hemorrhage (flow of blood from ruptured blood vessels), or the formation of a hematoma (localized swelling filled with blood resulting from a break in a blood vessel)
- Use the least constricting ring size that maintains your erection, since excessive constriction could injure the penis.



www.edenfantasys.com

Customer Service 24/7 Phone: +1 (770) 604 - 1352