

Rock hard head

PRODUCT MANUAL

This product is intended for adult use as a non-medical pleasure device only. Not for medical use. No medical claims are warranted or implied by the use of this product.



PRODUCT FEATURES

- 4 suction modes
- 5 massage modes
- Seductive voice modes
- USB rechargeable
- Made from soft TPE, silicone and ABS plastic

CHARGING

- For maximum pleasure charge before every use.
- Connect the included USB cable and insert the USB end into the wall adaptor or computer USB port (Computer must be turned on).
- The slow intermittent glow indicates charging in progress.
- A full charge takes up to 2 hours for 1.5 hours of play.
- Do not use the device while charging.

HOW TO USE

- Place the donut or sleeve on top of the cup.
- Before using the donut or sleeve for the first time, cut a hole according to the marking that fits your penis size.
- Apply water-based lubricant to your shaft.
- Pour a small amount of clean water into the cup.
- Water level should be lower than the exhaust hole, otherwise it will be blocked and cause the suction function to stop working. This is normal, you just have to pour the excess water out.
- The pump can be used without water.
- Insert a flaccid or semi-flaccid penis into the donut at the base of the pump.
- Hold **W** to turn the massage function on/off.
- Press it quickly to cycle through 5 massage modes. The LED light will flash.
- Hold **⌂** to turn the suction function on/off.
- Press it quickly to cycle through 4 suction modes. The LED light will flash.
- Start pumping slowly - you should feel a gentle tugging sensation.
- Press the **G** button to start letting the air out, and release to stop the air outlet. (Can adjust the suction rhythm by manual control.)
- After pumping session wear the cock ring around the penis to maintain the erection.

- If pain or discomfort occurs, immediately release pressure by holding the **G** button and discontinue use.
- Hold the **⌂** button to turn the seductive voice on/off.
- Press it quickly to cycle through 3 moans. The LED light will flash.

INCLUDES

- A pump, 3 cock rings, a sleeve, a donut, and a USB charger.

CLEANING AND CARE

- Remove the donut or sleeve for thorough cleaning.
- Use a toy cleaner/mild soap with water to clean the cylinder and the attachments before and after each use.
- Pat with a towel and allow it to air-dry completely.
- Dust the sleeve lightly with talc or cornstarch for better use.
- Store away from heat and sunlight.
- Do not get water inside the motorized unit as it is not waterproof.
- Use with water-based lube only, no silicone lubricants.
- Store away from other toys to avoid chemical reactions and damage to either toy.

PRECAUTIONS

- Apply only the minimum amount of vacuum pressure necessary to achieve an erection; overdoing it may bruise or injure the penis.

WARNING

- Stop using the vacuum pump if pain occurs.
- Do not use under the influence of alcohol or drugs, since it may impair the user's judgment and increase the risk of injury to the penis.
- Do not use if you have sickle cell disease, have a history of prolonged erections, or you are taking large quantities of aspirin or other blood thinners, as these conditions increase the risk of bruising and hematoma.
- Use of the device may bruise or rupture the blood vessels within the penis or scrotum, resulting in petechiae, hemorrhage, or the formation of a hematoma.
- Use of the device may aggravate already existing conditions such as Peyronie's disease (the formation of hardened tissue in the penis that causes pain, curvature, and distortion, usually during erection); priapism (persistent, usually painful erection of the penis as a consequence of disease and not related to sexual arousal); and urethral strictures (urethral stricture is an area of hardened tissue which narrows the urethra, sometimes making it difficult to urinate).
- Misuse of the vacuum pump could injure the penis.
- If you have symptoms of erectile dysfunction, i.e., inability to achieve an erection that is sufficient for sexual intercourse, consult your physician prior to using this device to avoid a potentially harmful delay in diagnosing any of the most common causes of this condition, such as diabetes, multiple sclerosis, cirrhosis of the liver, chronic renal failure, or alcoholism.
- Do not use the device if you have decreased sensation of pain in the area of the penis.
- Do not use the device if you have decreased hand strength because this may make removing the device difficult.

MANAGING COMMON PROBLEMS WITH A VACUUM DEVICE

| Problem | Likely cause | Remedy | Comments |
|--|---|---|--|
| No erection | No vacuum because of air leak caused by poor seal | Use more lubricant; apply firm pressure to the body; trim pubic hair; check the device for air leaks | Problem is most often associated with inexperience; it resolves as you become more adept at using the device |
| Partial erection | Incorrect cylinder size; incorrect insert or seal ring size; not enough practice sessions | More practice using device; use larger cylinder insert | Problem most often improves with continued use of device |
| Rapid loss of erection (in less than 5 minutes) | Vacuum lost because of air leak from faulty equipment, poor seal, inadequate lubrication, or excessive pubic hair | Same as for "No erection." Also: use smaller cylinder insert; use smaller or double tension rings; remove tension band carefully | Requires that you experiment with varying sizes of seal rings, inserts, and tension bands; see your physician if you need help or support to persevere |
| Delayed loss of erection (after 5 to 10 minutes) | Insufficient tension from bands or rings | Use smaller or combination of tension rings or bands; use the two-step application method (ask your physician about this) | |
| Pulling of the skin of the scrotum | Lubricant on scrotum; improper pumping technique; too large insert or seal ring; inexperience with system | Remove lubricant from scrotum; use smaller insert or seal ring; use the modified pumping technique (ask your physician about this); continue with practice sessions; angle cylinder downward during pumping | Problem may disappear as you become more adept at using the device. |
| Discomfort or pain: | | | |
| During pumping | Too rapid pumping; pulling of scrotal tissue | Slower pumping; continue to use device | Problem usually resolves as you become more adept at using the device |
| From tension ring | Tension ring too small; Anxiety | Use larger tension ring; continue to use device | Problem usually resolves as you continue to use the device |
| During intercourse | Inadequate lubrication; pressure on a sensitive area | More lubrication; position changes | |
| During ejaculation | Long period of abstinence; infection or inflammation of the prostate gland | Discontinue using device, consult your physician | |
| Redness, irritation, or bruising | Too rapid pumping; over pumping | Slower pumping; fewer pumps | Consult your physician if this problem persists past the first few practice sessions |
| Penis feels cold (to you or your partner) | Constriction of blood flow to the penis; lubrication | Wash off lubricant or warm lubricant before use | |
| Penis pivots on its base | Constriction of blood flow to the penis | If manageable, apply the device after you have a partial erection | |



Customer Service
10 AM - 7 PM EST
Phone: + 1 (770) 604 - 1352



www.edenfantasys.com